

J&L Hardware

The True Forming Back, or TFB, has been created to provide extreme comfort, unparalleled customization options and trouble-free adjustability. The hardware is durable, easily accessible, and is hidden with a hook-and-loop attached back for a clean, sleek look.

ltem	ID	Part Number	Description	Qty.
(1) (A1) (A2)	A1	TFB200-52	Niño T-Nut	1
	A2	SSS200-124	Slotted Seven Hole Adjustable L-bracket 90°	1
A3.0 .	A3	10 SSW	#10 Stainless Steel Washer	2
A. Mount	A4	10-32 x 1/2" BHS	10-32 x 1/2" Button Head Screw	2
B1 B2 B. Latch Assembly	B1	SSS200-07	1" 2 Hole J-Hook	1
	B2	1/4-20 x 5/8 BHS	1/4-20 x 5/8 Button Head Screw	2
	B3	1/4-20 LNN	1/4-20 Low Profile Lock Nut w/Nylon	2
<u> (4)</u>	C1	1/4-20 x 1 1/4 BHS	1/4-20 x 1 1/4" Button Head Screw	1
	C2	1/4-20 SAE FW	1/4-20 Washer	1
	C3	SSS200-36	1" Hold Down Drop Stop Weldment	1
	C4	67582247	5/16" 410 Internal Tooth-Lock washer	1
C. Back-Post Clamp	C5	1/4-20 x 7/16 RBW	1/4-20 x 7/16" Round Base Weldnut	1


Installation and Use


The J&L hardware includes features such as angle, width, and depth adjustments.

Angle Adjustment

Step One:

Loosen the 1x4-20 x 5/8" (B2) Button Head Screws on the Latch Assembly (B).






Step Two: Position the Back-Post Clamp (C) to the required angle.

> **Step Four:** Repeat for other mounting hardware as needed.


Step Three:


Secure the Back-Post Clamp (C) in place by tightening the screws (B2).




Width Adjustment

Step One: Loosen the 10/32 x 1/2" Button Head Screws (A4) on the Mount (A).







Step Two: Position the Mount (A) to the required width. **Step Three:** Secure the Mount (A) in place by tightening the screws (A4).




Depth Adjustment




Step One: Loosen and remove the 1/4-20 x 5/8" Button Head Screws (B2) on the Latch Assembly (B). **Step Two:** Position the Back-Post Clamp (C) to the required depth.






Step Three: Secure the Back-Post Clamp (C) in place by tightening the screws (B2).




Clamp Assembly to Wheelchair Back Post



Step Two: Slide the post into the correct vertical position with the J&L Latch Assembly (B).

Step Three: Slide the 1" Hold Down Drop Stop Weldment (C3) on top of the Latch Assembly (B).

STEP 3



Important

These products are designed to be fitted, applied, and installed exclusively by a health care professional trained for these purposes. The fitting, application and installation by a nonqualified individual could result in serious injury. **Stealth Products, LLC** accepts no liability for personal injury or damage that may arise from the failure of the user or other persons to follow the recommendations, warnings, and instructions in this manual. Stealth Products does not hold responsibility for final integration of final assembly of product to end user. Stealth Products is not liable for user death or injury. Initial setup and driving should be done in an open area free of obstacles until the user is fully capable of driving safely.

Before you begin using this product, it is important that you read and understand the content of these installation and operating instructions. Product misuse due to failure to adhere to instructions and warnings in this document will void your warranty and may result in property damage, injury or death. Always keep the operating instructions in a safe place so they may be referenced as necessary. If this document contains information you do not understand or if there are concerns about safety or operation, contact your provider.

All information, pictures, illustrations and specifications are based on the product information available at the time of printing, and are representative examples. They are not intended to be exact descriptions of the various parts of the product. Instructions are written with the expressed intent of use with standard configurations. They also contain important safety and maintenance information. For assistance with advanced configurations or options, contact your provider or **Stealth Products** at (512) 715-9995 or toll free at (800) 965-9229.

Immediately discontinue use if any function is compromised, if parts are missing or loose or if any component shows signs of excessive wear. Consult with your provider for repair, adjustment or replacement. You can download additional copies of this manual by visiting *https://stlpro.site/stealth-docs/* and searching for "P136D548" in the document manager.

Warranty

Our products are designed, manufactured, and produced to the highest of standards. If any defect in material or workmanship is found, **Stealth Products** will repair or replace the product at our discretion. Any implied warranty, including the implied warranties of merchantability and fitness for a particular purpose, shall not extend beyond the duration of this warranty. **Stealth Products, LLC** does not warrant damage due to, but not limited to, misuse, abuse, or misapplication of products and modification of product without written approval from **Stealth Products, LLC**. Any alteration or lack of serial number, where applicable, will automatically void this warranty. **Stealth Products, LLC** is liable for replacement parts only. and is not liable for any incurred labor costs. No person is authorized to alter, extend, or waive the warranties of **Stealth Products, LLC**.

Please visit *https://stlpro.site/returns-n-warranty* to learn more about our warranty and returns policy.

About Us

Stealth Products is committed to 100% customer satisfaction. Your complete satisfaction is important to us. Please contact us with suggestions or feedback to help us improve the quality and usability of our products.

You may reach us at:

Stealth Proc 104 John Kelly I Burnet, TX 7861	Drive, Fax: (Phone: (512) 715-9995 Toll Free: (800) 965-9229 Fax: (512) 715-9954 Toll Free: (800) 806-1225 info@stealthproducts.com - www.stealthproducts.com	
EC REP	CH REP	UK Authorized Representative	
MDSS GmbH Schiffgraben 41 30175 Hannover, Germany	SODIMED SA Chemin Praz Devant 12 1032 Romanel sur-Lausanne, Switzerland	MDSS-UK RP 6 Wilmslow Road, Rusholme Manchester M14 5TP, United Kingdom	ČÀ