




Backs and Support



All Purpose Hardware

True Forming Back's All Purpose (Knob) Hardware Owner's Manual

Stealth Products strives for 100% customer satisfaction. Your complete satisfaction is important. Please contact us with feedback or to suggest changes that may help improve the quality and usability of our products. You may reach us at:

Stealth Products, LLC 104 John Kelly Drive, Burnet, TX 78611

Phone: (512) 715-9995 Toll Free: (800) 965-9229 Fax: (512) 715-9954 Toll Free: (800) 806-1225 info@stealthproducts.com www.stealthproducts.com

General

Read and understand all instructions prior to the use of the product. Failure to adhere to instructions and warnings in this document may result in property damage, injury, or death. Product misuse due to failure to adhere to the following instructions will void the warranty.

Immediately discontinue use if any function is compromised, if parts are missing or loose, or if any component shows signs of excessive wear. Consult with your supplier for repair, adjustment, or replacement.

Important Information!

All persons responsible for fitting, adjustment, and daily use of the devices discussed in these instructions must be familiar with and understand all safety aspects of the devices mentioned. In order for our products to be used successfully, you must:

- read and understand all instructions and warnings;
- maintain our products according to our instructions on care and maintenance; and
- ensure devices are installed and adjusted by a trained technician.

Supplier Reference

Supplier:
Telephone:
Address:
Purchase Date:
Model:

Introduction 3.0

The installation instructions will guide you through the options and possibilities with the product.

Instructions are written with the expressed intent of use with standard configurations. They also contain important safety and maintenance information, as well as describe possible problems that can arise during use. For further assistance or more advanced applications, please contact your supplier or Stealth Products at (512) 715-9995 or toll free at (800) 965-9229.

Always keep the operating instructions in a safe place so they may be referenced as necessary.

All information, pictures, illustrations, and specifications are based on the product information that was available at the time of printing. Pictures and illustrations shown in these instructions are representative examples and are not intended to be exact depictions of the various parts of the product.

A CAUTION

These products are designed to be fitted, applied, and installed exclusively by a healthcare professional trained for these purposes. The fitting, application and/or installation by a non-qualified individual could result in serious injury.

Ordering Documentation

You can download additional copies of this user manual by accessing the Stealth website (www.stealthproducts.com) and searching "TFB Hardware All Purpose Owner's Manual" in the search bar at the top of the page.

Warranty 4.0

Our products are designed, manufactured, and produced to the highest of standards. If any defect in material or workmanship is found, Stealth Products will repair or replace the product at our discretion. Any implied warranty, including the implied warranties of merchantability and fitness for a particular purpose, shall not extend beyond the duration of this warranty. Stealth Products, LLC does not warrant damage due to, but not limited to:

- misuse, abuse, or misapplication of products; and/or
- modification of product without written approval from Stealth Products, LLC.

Any lack or alteration of serial number, where applicable, will automatically void this warranty.

Stealth Products, LLC is liable for replacement parts only. Stealth Products, LLC is not liable for any incurred labor costs.

No person is authorized to alter, extend, or waive the warranties of Stealth Products, LLC.

Stealth Products warrants against failure due to defective materials or workmanship:

Covers: 180 days

Hardware: 5 years

Electronics: 3 years

In Case of Product Failure

In the event of product failure covered by our warranty, please follow the procedures outlined below:

- 1. Call Stealth Products at (512) 715-9995 or toll free at (800) 965-9229.
- 2. Request a Return Authorization (RA) from the Returns Department and follow department documentation instructions.

1.0 Customer Satisfaction	i
2.0 Important Information	ii
3.0 Introduction	iii
4.0 Warranty	iv
5.0 Table of Contents	v
6.0 Warning Labels	vii
6.1 Warning Labels	vii
6.2 Limited Liability	vii
6.3 Testing	vii
7.0 Parts and Accessories	1
7.1 All Purpose (Knob) Hardware Package	1
7.2 All Purpose (Knob) Hardware Kit - Mount	2
7.3 All Purpose (Knob) Hardware Kit - Latch Assembly	3
7.4 All Purpose (Knob) Hardware Kit - Back Cane Clamp	4
8.0 Features	5
8.1 All Purpose (Knob) Hardware Features	5
8.2 Angle Adjustment	5
8.3 Depth Adjustment	6
8.4 Width Adjustment	6
8.5 Cane Compatibility	7
9.0 Installation Instructions	9
9.1 Preparations	9
9.2 Tools	9
9.3 Installation Plan	9
9.4 Required Tools/ Torque Chart	10
9.5 Installing the Hardware to the Back	11
9.6 Clamp Assembly to Wheelchair Back Cane	12

10.0	0 WC20 Information	13
	10.1 WC20 All Purpose (Knob) Hardware	.13
	10.2 Before Transit	.13
	10.3 Belt Placement	. 14
	10.4 User Safety	.16
11.	0 Maintenance	18
	11.1 Maintenance	.18
	11.2 Cleaning	.18
12.0	0 Notes	19

Warning Labels 6.0

Warning Labels

6.1

Warnings are included for the safety of the user, client, operator, and property. Please read and understand what the signal words **DANGER**, **WARNING**, **CAUTION**, **NOTICE**, and **SAFETY** mean, and how they could affect the user, those around the user, and property.



Limited Liability

6.2

Stealth Products, LLC accepts no liability for personal injury or damage to property that may arise from the failure of the user or other persons to follow the recommendations, warnings, and instructions in this manual. Stealth Products, LLC does not hold responsibility for final integration of final assembly of product to end user. Stealth Products, LLC is not liable for user death or injury.

Testing 6.3


Initial setup and driving should be done in an open area free of obstacles until the user is fully capable of driving safely.

All Purpose (Knob) Hardware Package

7.1

The following hardware is included for the mounting hardware:


Part Number*	Product Description*	
TFBMDM10 TFBMDM13 TFBMDM17 TFBMDM20	2-pt. or 4-pt. All Purpose (Knob) Complete Mounting Kit	



Note: The exact item number will depend on whether you have 2-pt. or 4-pt. mounting, and whether it is between the canes or a full-width configuration.

All Purpose (Knob) Kit - Mount Assembly

7.2




ID	Part Number	Description	Qty.
A1	TFB200-06	T-Nut	1
A2	SSS100-125/126	Back L-Bracket 90 Degrees Left/ Right	1
A3	1/4 SSW	1/4" Stainless Steel Washer	2
A4	1/4-20 x 5/8" BHS	1/4-20 x 5/8" Button Head Screw	2

Note: These items will typically come pre-installed on the back.

All Purpose (Knob) Kit - Latch Assembly

7.3




ID	Part Number	Description	Qty.
B1	3/8-16 PLK	3/8-16" Plastic Lobe Knob	1
B2	-	3/8-16" E-Clip	1
В3	SSS100-11-01	Universal Back Mount	1
В4	3/8-16 x 1 3/4" BHS	3/8-16 x 1 3/4" Button Head Screw	1

Note: These items will typically come pre-installed on the back.

All Purpose (Knob) Kit - Back Cane Clamp

7.4



ID	Part Number	Description	
C1	SSS100-11-02	Tube Clamp	1
C2	SSS100-11-04	1" Tube Spacer	1
C3	SSS100-11-03	Tube Clamp Bracket	1
C4	1/4-20 LNN	1/4-20 Low Profile Lock Nut w/ Nylon	2
C5	1/4-20 x 1/2 SHS	1/4-20 x 1/2" Socket Head Screw	2
C6	1/4-20 x 1 1/4 SHS	1/4-20 x 1 1/4" Socket Head Screw	2

Note: These items will typically come pre-installed on the back.

Features 8.0

All Purpose (Knob) Hardware Features

8.1

The **All Purpose** hardware includes angle, width, and depth adjustment features.

Angle Adjustment


8.2

Step One: Loosen the Knob (B1) on the Latch Assembly.

Step Two: Position the Back Cane Clamp (C) to the required angle.

Step Three: Secure the Back Cane Clamp (C) in place by tightening the Knob (B1).

Step Four: Repeat for other mounting hardware as needed.



5

Features 8.0


Depth Adjustment

8.3

Step One: Loosen the 1/4-20 X 1/2" Socket Head Screws (C5) on the Back Cane Clamp (C).

Step Two: Position the Back Cane Clamp (C) to the required depth.

Step Three: Secure the Back Cane Clamp (C) in place by tightening the screws (C5).




Width Adjustment

8.4

Step One: Loosen the 1/4-20 X 5/8" Button Head Screws (A4) on the Mount (A).

Step Two: Position the Mount (A) to the required depth.

Step Three: Secure the Mount (A) in place by tightening the screws (A4).




Features 8.0

Cane Compatibility

8.5

The **All Purpose** (Knob) Hardware is compatible with multiple cane sizes, and can be changed by switching out 1" Tube Spacer (C2) to either a smaller tube spacer to fit a 7/8" cane, or completely remove for a 3/4" cane.



Installation Instructions

Preparations 9.1

Only a qualified service technician may install the **True Forming Back** and its accessories.

A WARNING

An incorrect installation of the **TFB** and its accessories may cause damage to the hardware and/or injury to the user.

Tools 9.2

Use the proper tools to install and adjust the **TFB** to the desired position for the user. Ensure all torque specifications are followed.

! CAUTION

The use of improper tools may cause damage to the device. Not tightening to the torque specification can cause components to fail or cause discomfort to the user.

Installation Plan 9.3

Set up an installation plan before beginning the installation. This plan should take into account:

- where the **TFB** will be placed as well as applicable laterals and support cushions;
- how the TFB will be operated (the functions for the mount and laterals); and
- the amount of clearance necessary for other hardware and accessories.

A CAUTION

Any connection must always be secured with all delivered screws. Only use the screws provided in the package.

Required Tools 9.4

The tools needed to complete the installation are as follows:



Hardware	Component Use
5/32" hex key	Button Head Screws on Mount (A4), Socket Head Screws on Back Cane Clamp Assembly (C6)
3/16" hex key	Socket Head Screws on Back Cane Clamp Assembly (C5)
7/32" hex key	Button Head Screw on Latch Assembly (B4)

Tools are not provided. Refer to the manuals for additional accessories for the list of tools required for their installation.

Screws	Torque Specifications
1/4-20 x 5/8" Button Head Screw (A4)	125in-lbs
1/4-20 x 1 1/4" Socket Head Screw (C6)	200in-lbs
1/4-20 x 1/2" Socket Head Screw (C5)	200in-lbs
3/8-16 x 1 3/4" Button Head Screw (B4)	360in-lbs

Installing the Hardware to the Back

9.5

Step One: Take the T-nuts (B1) and slide them behind the aluminum frame (A1) of the back.


Step Two: Line the L-bracket (B2) with the T-nuts (B1) and ensure it is in the appropriate horizontal

and vertical position before securing it with two $1/4-20 \times 5/8"$ button head screws (B4).

Ensure each screw gets a 1/4" washer (B3) before tightening to 125in-lbs of torque.

Step Three: Take the latch assembly (C) and attach it with two 1/4-20 x 5/8" button head screws (C9) to the L-bracket (B2). Each screw gets a 1/4-20 lock nut (C1) and 1/4" washer (C8) to secure it. Before tightening to 125in-lbs of torque, ensure the assembly is positioned in the correct depth and angle needed.

See Section 10.1 for information on adjustment options.



Clamp Assembly to Wheelchair Back Cane

9.6

Step One: Visually determine the desired height of the **True Forming Back**. Mark on each back cane

the needed location to attach the clamp assemblies.

Step Two: Loosen the M5 x 0.8 x 25mm socket head cap screws (D8), and with two fingers, pinch and

hold the back of the cane clamp to open in order to slide the clamp assembly over the top of the back cane, receiving cane facing inward. Screws do not have to be completely removed


from hardware to slide clamp over the cane.

Step Three: Slightly tighten each M5 screw (D8). Align clamp assembly parallel to the wheelchair seat base.

Step Four: To achieve proper alignment, slightly move the mounting hardware in or out and/or up

and down. Make adjustments until the backrest smoothly attaches and removes from the top and bottom receiving canes.

Step Five: After final adjustments are complete, tighten all screws (D8) to 12nm of torque. This will



WC20 Quick Release Hardware

10.1

The **True Forming Back**'s **All Purpose** hardware, when used as part of a four-point mounting system, is WC20-approved. This configuration has met WC20 and ISO16840-4 requirements and provisions.

WC20 establishes design/performance requirements and test methods for complete seating systems (i.e., consisting of a seat, back support, and attachment hardware) as they relate to their use as seats in motor vehicles.

ACAUTION

The WC20-approved All Purpose hardware and True Forming Back should only be used as described in the manufacturer's instructions.

Before Transit 10.2

- Clients who use wheelchairs should transfer to the vehicle seat and use the vehicleinstalled occupant restraint systems.
- Prior to transporting, always check the tie-downs and hardware.
- Look for tears or worn webbing straps on tie-downs and restraints. Replace as necessary. *Never* use torn straps.
- Look for damaged hooks or loose tie-down hardware.
- On the seating system, check for loose screws attaching the hardware to the seat. These should be snug and not over-tightened.
- The **All Purpose** hardware should be securely attached to the back, and the transit pins should be properly inserted into the hardware.

DANGER

The WC20-approved All Purpose hardware and the True Forming Back are designed specifically for occupancy when used on wheelchairs that are facing forward in motor vehicles.

ADANGER

The WC20-approved **All Purpose** hardware and **True Forming Back** have been designed to accommodate the proper use of vehicle-anchored belt restraints and the ratings of the seating systems with regards to a) ease of properly positioning vehicle-anchored belt restraints on the wheelchair passenger, and b) the degree to which proper positioning of belt restraints can be achieved.

A DANGER


Do *not* alter or make substitutions to the seating system, its parts or components without first consulting the manufacturer.

Belt Placement 10.3

• The pelvic belt restraint should be worn low, across the front of the pelvis, near the junction of the pelvis and thighs.

- The belt restraint buckles of three-point belt restraints should be placed in contact with the occupant's body and away from wheelchair components.
- The junction of the shoulder belt and pelvic belt of three-point belt restraints should be located near the hip, opposite the shoulder over which the diagonal belt crosses, and not near the midline of the occupant.
- Upper torso belt restraints should fit directly over, and in contact with, the middle of the shoulder.

Proper Positioning of Belts on Occupant Shoulder Belt



!CAUTION

Belt restraints should be adjusted to fit as snugly as possible, consistent with user comfort.

Improper Positioning of Belts on Occupant




 Belt restraints should not be routed outside of the wheelchair wheels or over the wheelchair arm supports and should not be held away from the body by wheelchair components or parts.

SAFETY

Belt restraints should not be worn twisted in a manner that reduces the area of contact of the belt webbing with the occupant.

Both pelvic-belt and shoulder-belt restraints that comply with RESNA WC-4:2012, Section 18 and/or 4.6, 5.2, 5.3 or RESNA WC-4:2012, Section 19 should be used to limit occupant movement in a crash, and to reduce the likelihood of occupant ejection from the vehicle and/or injurious contact of the occupant with the vehicle interior.

The pelvic belt should be angled between 30° and 75° horizontally when viewed from the side, and ideally between 45° and 75° horizontally, as shown in the figure below.



AWARNING

Back supports with adjustable recline angles should not be tilted back more than 30° to the vertical during travel in vehicles unless necessary for the medical and postural needs of the wheelchair occupant.

AWARNING

If the back support must be adjusted to an angle greater than 30° to the vertical during travel, the upper shoulder belt anchor point should be adjusted rearward to maintain belt contact with the wheelchair occupant's shoulder and chest.

Trays

Wheelchair-mounted rigid trays not specifically designed for use during travel in vehicles should be:


- removed and secured separately in the vehicle; or
- secured to the wheelchair so they will not break free in a crash;
- positioned with a gap of at least 3in. (75mm) between the back edge of the tray
 and the wheelchair occupant's abdomen/chest, so as not to interfere with proper
 belt-restraint use; and
- equipped with energy-absorbing padding between the back edge of the tray and the wheelchair occupant.

User Safety 10.4

The use of a postural pelvic belt attached to the wheelchair base or seat frame is encouraged during travel, but these belts should be positioned so that they do not interfere with the proper positioning of crashworthy belt restraints, and they should not be relied upon for occupant protection in crash situations unless the postural belt has been designed to comply with, and perform to, the requirements in 4.6, 5.2, and 5.3 of RESNA WC-4:2012, Section 19.

Sufficient forward and rearward clear space should be provided around the wheelchair occupant.

The forward clear-space zone (FCZ) needs to be larger when not utilizing a shoulder-belt restraint.



When mounting the WC20-approved **All Purpose** hardware to your **True Forming Back**, refer to the *Installation Instructions* section starting on page 8.

Torque specifications for the hardware are listed in the *Installation Instructions* section on page 10.

ADANGER

The WC20-approved All Purpose hardware and True Forming Back are designed ONLY for use with wheelchair frames that have been successfuly crash-tested to the frontal impact requirements of RESNA WC-4:2012, Section 19

AWARNING

The WC20-approved **All Purpose** hardware and **True Forming Back** *must* be used on a wheelchair frame that provides four securement points and pelvic-belt anchor points that conform to the requirements of RESNA WC-4:2012, Section 19.

Maintenance 11.0

Maintenance 10.1

These care and guideline instructions will keep the hardware in good condition for a longer period of time and prevent damage:

- Check and re-tighten all fasteners to the proper torque specifications on a regular basis. Reference the installation manual to find proper torque specs.
- Repair or replace parts as needed.
- Gently remove dust and dirt from hardware with a soft, damp cloth.

Cleaning 10.2

- Use a soft, damp cloth to clean the hardware.
- Ensure all cleaners are approved for finished steel, aluminum, plastic, and upholstered surfaces.
- Full cleaning and maintenance instructions can be found in the True Forming Back manual.

A CAUTION

Always check all mounting hardware, making sure each fastener is properly tightened before using the back support.

SAFETY

Replace or repair parts as needed.

CAUTION

250lbs (113.40 kg) user weight limit.

NOTICE

Improper installation or altering a back in any way will void the warranty.

Notes	12.0





Stealth Products, LLC. • info@stealthproducts.com • www.stealthproducts.com +1(800) 965-9229 | +1(512) 715-9995 | 104 John Kelly Drive, Burnet TX 78611

Revision Date 2019-01-31